

State Of New Mexico
Energy, Minerals, and Natural Resources

WATER CONSERVATION DIVISION

2040 South Pacheco
Santa Fe, NM 87505Form C-103
Revised March 25, 1999

Well API No.	30-015-22955
5. Indicate Type Of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
6. State Oil and Gas Lease No.	648
7. Lease Name Or Unit Agreement Name:	State G Com
8. Well No.	001
9. Pool Name Or Wildcat	Angell Ranch; Atoka Morrow

SUMMARY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type Of Well:

Oil Well ☐ Gas Well ☒ Other ☐

Name Of Operator

Ray Westall Operating

Address Of Operator

P.O. Box 4 - Loco Hills, New Mexico 88255

Well Location

Unit Letter E : 1980' Feet From The North Line And 660' Feet From The West LineSection 24 Township 19S Range 27E NMPM County Eddy

10. Elevation (Show whether DR, RKB, RT, GR, ect.)

11. Check The Appropriate Box To Indicate Nature Of Notice, Report Or Other Data

NOTICE OF INTENTION TO:

Remedial Work ☐ Plug And Abandon ☒

Temporarily Abandon ☐ Change Plans ☐

Pull Or Alter Casing ☐ Multiple Completion ☐

Other ☐

SUBSEQUENT REPORT OF:

Remedial Work ☐ Alter Casing ☐

Commence Drilling OPNS. ☐ Plug and Abandonment ☐

Casing Test and Cement Job ☐

Other: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Notify NMOCD 24 hours prior to starting.

MIRU plugging unit. NU BOP. Release packer and TOH with tubing and packer.

Spot 10 sxs cement @ 10,010.

TIH with OE tubing and spot 10 ppg md 9890' to 8680'. Spot ~~100~~ ^{25 SX} plug @ 9400' - Tag.Pull tubing to ~~8600'~~ and spot ~~100'~~ cement plug across top of ~~Penn 8680' to 8580'~~.

POH with tubing.

Pull on casing to determine free point. Cut, pull and LD 4 1/2" casing. TOC - 7820'

RIH with OE tubing to + 8580' and displ hole with 10 ppg salt gel mud.

Pull tubing to 4 1/2" casing stub and spot 100' cement plug (50' in and 50' out). Tag TOC

Set 100' cement plug 2000' above 4 1/2" casing stub.

Set 100' cement plug across 8 5/8" casing shoe 2492'-2392'. Tag TOC

Set 100' cement plug across 11 3/4" surface shoe 373' - 273'.

^{60'} Set ~~35~~ cement plug @ surface with ~~sxs~~.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signature Rene Mathews Title Production Secretary Date 04/26/02Type Or Print Name: Rene Mathews Telephone No. (505) 677-2370

(THIS SPACE FOR STATE USE)

APPROVED BY

Conditions Of Approval If Any:

Title

Date

MAY 2 2002