

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

NM OIL CONS. COM. 47
SUBMIT IN TRIPLEX
Drawers (Other instructions on reverse side)
Artesia, NM 88210

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 13627

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Pecos River "20" Fed. Com.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

McMillan Upper Penn

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 20, T-19-S, R-27-E

12. COUNTY OR PARISH 13. STATE

Eddy

N.M.

1. OIL WELL ☐ GAS WELL ☒ OTHER

APR 22 1983

2. NAME OF OPERATOR

Southland Royalty Company

O. C. D.

3. ADDRESS OF OPERATOR

21 Desta Drive, Midland, Texas 79701

ARTESIA, OFFICE

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

1980' FS & EL, Sec. 20, T-19-S, R-27-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3392' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Notify Minerals Management 24 hrs prior to starting.
2. MIRU plugging ut. & pull pkr seal assembly & tbg from wellbore.
3. RIH w/retrieving tool & pull pkr.
4. RIH w/CIBP on WL & set @ 8150' & dump 35' cmt on same. POH.
5. Pull on csg, find freepoint & shoot off 4 1/2" csg (approx 7100') & pull same.
6. GIH w/tbg & displace hole w/9-10 ppg salt gel mud.
7. Pull up hole & spot 150' cmt plug across 4 1/2" csg stub.
8. Spot 100' cmt plug from 2575' to 2475'.
9. Spot 100' cmt plug across 8 5/8" csg shoe from 2056' to 1956'.
10. Spot 50' cmt plug at surface.
11. Cut off WH, install dry hole marker, RD MO & restore location.

Above discussed w/Peter Chester on 3/24/83.

RECEIVED

APR 14 1983

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Operations Engineer DATE 4/13/83

(This space for Federal or State office use)

APPROVED BY (Orig. W. CHESTER)
CONDITIONS OF APPROVAL, IF ANY:

APR 21 1983

TITLE

DATE