

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
OMB No. 1004-0135  
Expires November 30, 2000

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or re enter an  
an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1 Type of Well

☐ Oil well ☐ Gas Well ☐ Other

2 Name of Operator

Yates Petroleum Corporation /

a. Address

105 South Fourth Street

3b. Phone No. (include area code)

505-748-1471

4 Location of Well

(Footage, Sec., T., R., M., OR Survey Description)

1980' FNL and 660' FEL Sec. 25-T20S-24E Unit H SENE

5. Lease Serial No.

NM-34647

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.

Charlette McKay Federal SWD #1

9. API Well No.

30-015-23095

10. Field and Pool, or Exploratory Area

SWD-Devonian

11. County or Parish, State

Eddy NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

☒ Notice of Intent

☐ Acidize

☐ Deepen

☐ Production (Start/Resume)

☐ Water Shut-Off

☐ Alter Casing

☐ Fracture Treat

☐ Reclamation

Well Integrity

☐ Subsequent Report

☐ Casing Repair

☐ New Construction

☐ Recomplete

☐ Other

☐ Change Plans

☒ Plug and Abandon

☐ Temporarily Abandon

☐ Final Abandonment Notice

☐ Convert to Injection

☐ Plug Back

☐ Water Disposal

13 Describe Proposed or Completed Operation ( clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof.  
If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones.  
Attach the Bond under which the work will be performed or provide the Bond no. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days.  
following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once  
testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have completed, and the operator has  
determined that the site is ready for final inspection.)

Propose to plug & abandon as follows:

1. TOH with 2-7/8" tubing, laying down the PC tubing.
2. TIH with WL to set CIBP @ 9640'. TIH with tubing load hole with plugging mud, and spot a 5 sack Class C Cement on top of the CIBP. Pull tubing up the hole and reverse circulate the tubing clean.
3. Spot a 10 sack Class C cement plug over the Morrow top from 9056' to 9156.
4. Spot 25 sacks Class C cement plug across the Atoka perforations from 8,834' to 9044' in the 5.5" casing.
5. Spot a 10 sack Class C cement plug over the Wolfcamp top from 6,056' to 6,156. Pull tubing up

Continue on next page.

14 I hereby certify that the foregoing is true and correct  
Name (Printed/Typed)

Erma Vazquez

Title

Drilling Technician

Signature

*Erma Vazquez*

Date

26-Dec-01

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Conditions of approval, if any, are attached. Approval of this notice does not warrant or  
certify that the applicant holds legal or equitable title to those rights in the subject lease  
Which would entitle the applicant to conduct operations thereon.

Title

Date

Office

Title

Signature

Accepted for record

only 1-9-02

for any person knowingly and willfully to make to any department or agency of the United  
y matter within its jurisdiction

Charlette-mcKay SWD No 1  
Sec 25-T20-R24E  
Eddy County, NM

hole and reverse circulate the tubing clean.

6. RU WL and free point 5.5" csing, cut the casing at the free point and pull casing. The free point should be @ +/-5,600'.

7. TIH with tubing load hole with plugging mud and spot 40 sacks Class C cement plug across the 5.5" casing stub.

8. TIH with tubing load hole with plugging mud nd spot 40 sacks Class C cement plug form +/-3,550' to 3,650', 2000' above the casing stub in the 7875" open hole. Pull tubing up the hole and reverse circulate the tubing clean.

9. Spot a 40 sack Class C cement plug over the Glorieta top from 2,186' to 2.286. Pull tubing up hole and reverse circulate the tubing clean.

10. Spot 40 sacks Class C cement plug from 1,950 to 2,050' across the 8.625" intermediate casing shoe.

11. Spot 40 sacks Class C cement plug from 305' to 405' across the surface casing shoe.

12. Spot 15 sac Class C cement plug at surface.

13. Remove all surface equipment and weld dry hole marker per regulations.