

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. DIV-Dist. 2
1301 W. Grand Avenue
Artesia, NM 88210

FORM APPROVED
OMB No. 1004-0135
Expires November 30, 2000

0155

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or re enter an
an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1 Type of Well

☐ Oil well ☐ Gas Well ☐ Other

2 Name of Operator

Yates Petroleum Corporation

a. Address

105 South Fourth Street

3b. Phone No. (include area code)

505-748-1471

4 Location of Well

(Footage, Sec., T., R., M., OR Survey Description)

1980' FNL and 660' FEL Sec.25-T20S-24E Unit H SENE

5. Lease Serial No.

NM-34647

6. If Indian, Allottee or Tribe Name

7 If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.

Charlette McKay Federal SWD #1

9. API Well No.

30-015-23095

10. Field and Pool, or Exploratory Area

SWD-Devonian

11. County or Parish, State

Eddy NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

☒ Notice of Intent

☐ Acidize

☐ Deepen

☐ Production (Start/Resume)

☐ Water Shut-Off

☐ Alter Casing

☐ Fracture Treat

☐ Reclamation

Well Integrity

☐ Subsequent Report

☐ Casing Repair

☐ New Construction

☐ Recomplete

☐ Other

☐ Change Plans

☒ Plug and Abandon

☐ Temporarily Abandon

☐ Final Abandonment Notice

☐ Convert to Injection

☐ Plug Back

☐ Water Disposal

13 Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof.
If the proposal is to deepen directionally or recompleate horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones.
Attach the Bond under which the work will be performed or provide the Bond no. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days
following completion of the involved operations. If the operation results in a multiple completion or recompleation in a new interval, a Form 3160-4 shall be filed once
testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have completed, and the operator has
determined that the site is ready for final inspection.)

Propose to plug & abandon as follows:

1. TOH with 2-7/8" tubing, laying down the PC tubing.

2. TIH with WL to set CIBP @ 9640'. TIH with tubing load hole with plugging mud, and spot a 5 sack
Class C Cement on top of the CIBP. Pull tubing up the hole and reverse circulate the tubing clean.

3. Spot a 10 sack Class C cement plug over the Morrow top from 9056' to 9156.

4. Spot 25 sacks Class C cement plug across the Atoka perforations from 8.834' to 9044' in the 5" casing.

5. Spot a 10 sack Class C cement plug over the Wolfcamp top from 6,056' to 6,156. Pull tubing up.

Continue on next page.

14 I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Erma Vazquez

Title

Drilling Technician

Signature

Erma Vazquez

Date

26-Dec-01

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

(ORIG. SGD.) ALEXIS C. SWOBODA

PETROLEUM ENGINEER

Date

JAN 09 2002

Conditions of approval, if any, are attached. Approval of this notice does not warrant or
certify that the applicant holds legal or equitable title to those rights in the subject lease
Which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United
States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction

Accepted for record

JAN 23 2002

only

APPROVAL SUBJECT TO
GENERAL REQUIREMENTS AND
SPECIAL STIPULATIONS ATTACHED

U.S. AIR FORCE
HEADQUARTERS
WASHINGTON, D.C.

APPROVAL SUBJECT TO
GENERAL REQUIREMENTS AND
SPECIAL STIPULATIONS ATTACHED

100-100000-100000

100-100000-100000

100-100000-100000

Charlette-mcKay SWD No 1
Sec 25-T20-R24E
Eddy County, NM

hole and reverse circulate the tubing clean.

6. RU WL and free point 5.5" casing, cut the casing at the free point and pull casing. The free point should be @ +/-5,600'.

7. TIH with tubing load hole with plugging mud and spot 40 sacks Class C cement plug across the 5.5" casing stub.

8. TIH with tubing load hole with plugging mud and spot 40 sacks Class C cement plug from +/-3,550' to 3,650', 2000' above the casing stub in the 7875" open hole. Pull tubing up the hole and reverse circulate the tubing clean. ~~TAG~~

9. Spot a 40 sack Class C cement plug over the Glorieta top from 2,186' to 2,286'. Pull tubing up hole and reverse circulate the tubing clean.

10. Spot 40 sacks Class C cement plug from 1,950 to 2,050' across the 8.625" intermediate casing shoe.

11. Spot 40 sacks Class C cement plug from 305' to 405' across the surface casing shoe.

12. Spot 15 sac Class C cement plug at surface.

13. Remove all surface equipment and weld dry hole marker per regulations.