

PROPOSED WELL PLAN

WELL NAME Preston Federal Com. No. 2 FIELD Dagger Draw, South

<u>ATTACHMENT</u>	<u>NO.</u>	<u>REQUIRED</u>	<u>NOT REQUIRED</u>
CASING CENTRALIZERS, SCRATCHERS	<u>          </u>	<u>      X      </u>	<u>                  </u>
CEMENTING	<u>          </u>	<u>      X      </u>	<u>                  </u>
MUD PROGRAM	<u>          </u>	<u>      X      </u>	<u>                  </u>
WELL PLAN OUTLINE	<u>          </u>	<u>      X      </u>	<u>                  </u>
PORE PRESSURE - FRAC GRADIENT	<u>          </u>	<u>                  </u>	<u>                  </u>
PROJECTED PROGRESS	<u>          </u>	<u>                  </u>	<u>                  </u>
CROSS SECTION OR WELL COURSE	<u>          </u>	<u>                  </u>	<u>                  </u>
HYDRAULICS PROGRAM	<u>          </u>	<u>                  </u>	<u>                  </u>
BIT PROGRAM	<u>          </u>	<u>                  </u>	<u>                  </u>
VENDER USAGE LIST	<u>          </u>	<u>                  </u>	<u>                  </u>

DRILLING AND COMPLETION PROCEDURE

1. 0'-500' - Drill a 17-1/2" hole. Run and cement 13 3/8" casing (See cement & casing programs). WOC 18 hours. Pressure test casing to 600 psi for 30 mins.
2. 500'-1200' - Drill a 12-1/4" hole. Run and cement 9-5/8" casing (See cement & casing programs). WOC 18 hours. Pressure test casing to 600 psi for 30 mins.
3. 1200'-9800' - Drill a 8 3/4" hole. Drill out shoe and pressure test formation to 200 psi. Run open hole logs, run, and cement casing (See casing & cement programs).
4. Detailed completion procedure to be prepared after open hole logs are analyzed. Anticipate a Morrow/Gisco Dual completion.