

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a reservoir. Use Form 9-331-C for such proposals.)

RECEIVED BY

JUL -3 1986

O. C. D.

ARTESIA, OFFICE

1. oil ☐ gas ☒ other ☐  
well well

2. NAME OF OPERATOR

Robert N. Enfield

3. ADDRESS OF OPERATOR

P.O. Box 2431, Santa Fe, NM 87504-2431

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

1835' FNL & 2310' FWL of Sec. 5

AT SURFACE:

AT TOP PROD. INTERVAL:

AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

CHANGE ZONES ☐

ABANDON\* ☒

(other)

SUBSEQUENT REPORT OF:

5. LEASE

NM-45227

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Chevron Federal Comm.

9. WELL NO.

1

10. FIELD OR WILDCAT NAME

Undesignated Penn

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 5, T19S, R27E

12. COUNTY OR PARISH

Eddy

NM

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)

3280 GL

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Set #1 CIBP at 7900' with 100' cement on CIBP (7900' - 7800')

Set #2 plug (150' cement) 7225' - 7075' Wolfcamp

Freepoint (shoot off 4-1/2" casing, pull same for recovery)

Set #3 plug (150' cement) stub in/out 4-1/2" tag plug

Set #4 plug (100' cement) approximately 4000' - 5000'

Set #5 plug (100' cement) 3975' - 5875' Bone Springs

Set #6 plug (100' cement) 2458' - 2358' 8-5/8 in/out tag plug

Set #7 plug (100' cement) 1650' - 1550' San Andres

Set #8 plug (100' cement) 1350' - 1250' Greyburg

Set #9 plug (100' cement) 350' - 250' 13-3/8" casing

Set #10 plug (0'-50')

cut off casing approximately 4' below ground level.

Weld on plate, set dry hole marker, prepare location.

\*Plugging instructions by BLM carlsbad, NM (Bob Pitschki) 6/18/86

\* Subsurface Safety Valve: Manu. and Type

Set @ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

Robert N. Enfield

TITLE

Operator

DATE

6/24/86

Robert N. Enfield

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: