

## OIL CONSERVATION DIVISION

Operator <u>Yates Petr Corp</u>		Lease <u>Dagger "ZW"</u>		Well # <u>2</u>	
Location of Well	Unit <u>I</u>	Section <u>25</u>	Township <u>19</u>	Range <u>24</u>	County <u>Eddy</u>
Drilling Contractor <u>Undesignated</u>			Type of Equipment <u>Rotary</u>		
<p><b>* Witness</b>      <u>APPROVED CASING PROGRAM</u></p>					
Size of Hole	Size of Casing	Weight Per Foot	New or Used	Depth	Sacks Cement
<u>14 3/4</u>	<u>* 9 5/8</u>	<u>36# J-55</u>		<u>1150</u>	<u>925 Circ</u>
<u>8 3/4</u>	<u>7</u>	<u>26# K-55 &amp;</u>		<u>TD</u>	<u>400</u>
		<u>N-80, 23# K-55</u>		<u>approx 8000</u>	
Casing Data:					
Surface _____ joints of <u>9 5/8"</u> inch <u>36</u> # Grade <u>J-55</u>					
(Approved) (Rejected)					
Inspected by <u>M.S.</u> date <u>2-28-90</u>					
Cementing Program					
Size of hole <u>12 1/4"</u> Size of Casing <u>9 5/8"</u> Sacks cement required _____					
Type of Shoe used <u>guide</u> Float collar used <u>insert</u> Btm 3 jts welded <u>yes</u>					
TD of hole <u>1208'</u> Set <u>1208'</u> Feet of <u>9 5/8"</u> Inch <u>36</u> # Grade <u>J-55</u>					
New-used csg. @ <u>1208'</u> with <u>200 22cc</u> sacks neat cement around shoe					
+ <u>900sx</u> sax <u>pacesetter lite</u> additives ( <u>10# hyseal, 1/2# celloseal, 370cc</u> )					
Plug down @ <u>2:30</u> (AM) (PM) Date <u>3-4-90</u>					
Cement circulated <u>yes</u> No. of Sacks <u>125 sx</u>					
Cemented by <u>Western Company</u> Witnessed by <u>Mike Stubblefield</u>					
Temp. Survey ran @ _____ (AM) (PM) Date _____ top cement @ _____					
Casing test @ _____ (AM) (PM) Date _____					
Method Used _____ Witnessed by _____					
Checked for shut off @ _____ (AM) (PM) Date _____					
Method used _____ Witnessed by _____					
Remarks: _____					
last drls break @ 990'					