BURE SUNDRY N	UNITED STATES NM OIL CONS O ARTMENT OF THE INTERIODrawer DD EAU OF LAND MANAGEMENTrtesia, NM OTICES AND REPORTS ON WELLS	88210 Budget Bureau No. 1004-0135 Expires: March 31, 1993 5. Lease Designation and Serial No. NM10190 6. If Indian, Allonge of Trate Name
	sais to drill or to deepen or reentry to a different TION FOR PERMIT—" for such proposals	nt reservoir.
	SUBMIT IN TRIPLICATE	7. If Unit or CA. Agreement Designation 14-08-001-11572
Type of Well Oil Gas Well Other Name of Operator		8. Well Name and No. East Shugart Unit #34
Devon Energy Corporation (Nevada) 3. Address and Telephone No.		9. API Well No. 30-015- 26483
	00, OKC, OK 73102-8260 405/235-3 er Servey Description)	
990' FNL & 2310' FWL, S	ec. 3-T19S-R31E, Unit C	13. County or Parish, State Eddy, NM
	E BOX(S) TO INDICATE NATURE OF NOTI	CE, REPORT, OR OTHER DATA
	Түре	OF ACTION
Notice of latest	Abandeamant Decompletion Prograg Back	Change of Plans Change of Plans New Construction Nen-Routine Fracturing
Final Abandonment Notice	Coming Repair Altering Coming Coher run integrity	
Describe Proposed or Completed Operations (Cle give subsurface locations and measured and	arry state all pertinent details, and give pertinent dates, including estimat 6 eres vertical depths for all markers and some pertinent to this work.	(Ness: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) led date of starting any proposed work. If well is directionally drilled.) ^o
	NOW I	
(1)	O. C Set a packer at ±2600'. ARTESIA,	QEFICE_
(2)	Rig up pump truck on casing.	JUN 20 AREA
(3)	Load casing with water and pressure test to	500 psi for 30 mins. \square \square
The BL	M will be notified 24 hours prior to testing.	
hereby certify that the foregoing is true and cor		

Signed Candace P. Fraham	Time Engineering Tech.	06-15-94
(This space for Federal or Size office use)	Determine without spec	· ·
Approved by Conditions of approval, if any:	Title	Dee:
- SEE ATTACHES -		
Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly or representations as to any mamer within its jurisdiction.	y and willfully to make to any department or spancy of the Unio	ed States any false, fictitious or fraudulent assuments

or representations as to any matter within its jurisdiction

(Rev. 5/23/94)

BUREAU OF LAND MANAGEMENT CARLSBAD RESOURCE AREA

Temporary Abandonment of Wells on Federal Lands

Conditions of Approval

According to 43 CFR 3162.3-4-c, "No well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer".

Temporary Abandonment (TA) status approval requires a successful casing integrity test as follows:

1. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County call (505) 887-6544 ; for wells in Lea County call (505)393-3612.

2. A bridge plug or packer shall be set at a maximum of 50 feet above any open perforations or open hole.

3. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.

4. The production casing shall be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leak-off.

Wells that successfully pass the casing integrity test will be approved for Temporary Abandonment (TA) status for 12 months provided that the operator: $\dot{C}_{1} \subset \mathcal{D}_{2}$

1. Submits a subsequent Sundry Notice requesting TA approval,

2. Attaches a clear copy or the original of the pressure test chart,

3. And attaches a detailed justification why the well should not be plugged and abandoned.

The TA status could be extended without another casing integrity test provided there was no leak-off during the test.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

1. A procedure to repair the casing so that a TA approval can be granted.

2. A procedure to plug and abandon the well.