

total loss does occur, the remainder of the hole will be dry drilled with sweeps to 3800 ft.

SURFACE PIPE - 325 FT OF 8 5/8" IN 11" HOLE:

Attempt to circulate 175 sx with Class "C" cement and 2% CACL and 1/4 lb/sack of cellophane flakes. A "Texas" pattern guide shoe and insert float valve will be run, along with 3 centralizers on bottom 300 ft of string. Thread socking compound should be used on bottom two joints of casing.

PRODUCTION CASING - 3800 FT OF 5 1/2" IN 7 7/8" HOLE:

Production casing will be cemented with 200 sx Class "H" with 5 lb/sack salt and some fluid loss additive. This should be sufficient to bring the cement 700' above the bottom of the hole.

↙  
circulate to  
the surface.

(SJS)