

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division
311 S. 1st St.
Albuquerque, NM 88210-2834

FORM APPROVED
Budget Bureau No. 1004 0135
Expires: March 31, 1993

C/S F

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION

(505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

990' FSL & 990' FEL of Section 23-T20S-R24E (Unit P, SESE)

5. Lease Designation and Serial No.

NM-27055

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Prickly Pear AIE Fed Com

9. API Well No.

#1

30-015-26738

10. Field and Pool, or Exploratory Area

Undes. Strawn/Wolfcamp

11. County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☒ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
- ☐ Change of Plans
☐ New Construction
☐ Non Routine Fracturing
☐ Water Shut Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well is presently producing out of perforations 7591-7773' (Canyon). Propose to recomplete to Strawn or Wolfcamp as follows:

1. TOOH with rods and tubing.
2. TIH with bit, scraper and tubing. Clean out to 8075' with 2% KCL water. TOOH.
3. Perforate 7988-8004' (Strawn). Acidize as necessary.
4. Swab test.
5. If Strawn is commercial, will squeeze Canyon as follows:
 - a. Set blanking plug in packer. TOOH with tubing.
 - b. TIH and set RBP above packer. Drop 75' of sand on top of RBP. Tag to make sure sand landed.
 - c. Set cement retainer at 7500' and squeeze with 500 sacks Class C cement + .3% fluid loss additive to squeeze perforations 7591-7773' (Canyon).
 - d. Drill out cement and retainer, test casing, pull RBP and clean out to packer.

If Strawn is uncommercial, will proceed with Wolfcamp recompletion as follows:

1. Set a CIBP at 7950' and cap with 20' of cement.
2. Set a CIBP at 7525' and cap with 20' of cement.
3. Perforate 6707-6723' (Wolfcamp), acidize as necessary.

14. I hereby certify that the foregoing is true and correct

CONTINUED ON NEXT PAGE:

Signed

Rusty Allen

Title Operations Technician

Date Jan. 5, 1998

(This space for Federal or State office use)

Approved by

(ORIG. SGD.) LES BABYAK

Title

PETROLEUM ENGINEER

Date

JAN 07 1998

Conditions of approval, if any:

WINTERMOUNT
NM 12

26 96 117

RECEIVED


YATES PETROLEUM CORPORATION
Prickly Pear AIE Federal Com #1
Section 23-T20S-R24E
Eddy County, New Mexico

SUNDRY NOTICE FOR RECOMPLETION CONTINUED:

4. Swab test.
5. If Wolfcamp is commercial, place well into production.

If Strawn and Wolfcamp are non-commercial, will Temporarily Abandon as follows:

1. Pull all tools out of hole.
2. Set a CIBP at 6650' and cap with 10' of cement.
3. Circulate treated 2% KCL water for packer fluid.
4. Flange 2" ball valve to casing head.
5. Perform Mechanical Integrity Test - 500 psi for 35 minutes.



Rusty Klein
Operations Technician
January 5, 1998