

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION
JUL 11 1974
O. C. C.
ARTESIA, OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		5. State Oil & Gas Lease No. G-7815
2. Name of Operator Gulf Oil Corporation		7. Unit Agreement Name
3. Address of Operator P. O. Box 670, Hobbs, N.M. 88240		8. Farm or Lease Name Eddy "AV" State (NCT-A)
4. Location of Well UNIT LETTER I 1650 FEET FROM THE south LINE AND 330 FEET FROM THE east LINE, SECTION 21 TOWNSHIP 19S RANGE 28E NMPM.		9. Well No. 2
15. Elevation (Show whether DF, RT, GR, etc.) 3399' GL		10. Field and Pool, or Wildcat E. Millman Q. Gbr.
		12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1773' TD. 1763' PB. P₁ 697-1717

Set CIBP at 1660' and circulate abandonment mud. Spot 35' cement plug on top of CIBP. Cut 4-1/2" casing at approximately 950' and recover same. Set 100' cement plug across 4-1/2" casing stub. Set cement plug across Yates from 650-750'. Set cement plug from 200-300' across 8-5/8" casing shoe. Set 50' surface plug and install dry hole marker.

NOTE: If unable to recover 4-1/2" casing, set CIBP at 1660' and circulate abandonment mud. Spot 35' cement plug on top of CIBP. Set 50' surface plug and install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *B. J. Barkatz* TITLE Area Engineer DATE 7-10-74

APPROVED BY *W. A. Gressitt* TITLE OIL AND GAS INSPECTOR DATE JUL 12 1974

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

Plus...