Submit 3 Copies to Appropriate District Office

CONDITIONS OF APPROVAL, IF ANY:

State of New Mexico Energy, Ivanierals and Natural Resources Department

~1/	
51	For
	R.
Al.	

Firm C-160 Revised 1-1-89

District Office DISTRICT I P.O. Box 1980, Hobbs, NM 88240 P.O. Box 2088 P.O. Box 2088	WELL API NO. 30-0125-22625
DISTRICT II P.O. Drawer DD, Artesia, NM 88210 Santa Fe, New Mexico 87504-2088	5. Indicate Type of Lease STATE X FEE
DISTRICT III 1000 Rio Brizos Rd., Azioc, NM 87410	6. State Oil & Gas Lease No. L-6654
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	7. Lease Name or Unit Agreement Name State: 19 Com
I. Type of Well: Oil Well X Well OTHER	8. Well No.
2. Name of Operator V-F Petroleum Inc.	9. Pool name or Wildcat
3. Address of Operator P. O. Box 1889 Midland, TX 79702	Millman (Strawn)
4. Well Location Unit Letter N 860 Feet From The South Line and 2	County
Section 19 Township 19-S Range 28-F 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3,493' GL	NMPM VIIII
Check Appropriate Box to Indicate Nature of Notice NOTICE OF INTENTION TO:	JBSEQUENT REFORM 51.
PERFORM REMEDIAL WORK X PLUG AND ABANDON REMEDIAL WORK	1 1
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL	
PULL OR ALTER CASING CASING TEST AND	O CEMENT JOB L
OTHER.	
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, work) SEE RULE 1103.	including estimated date of starting any proposed
See reverse	A 25 26 30 37
	RECEIVED OCD ARTESIA
	्य शराहा जा गाउँ।
I hereby certify that the information above is true and complete to the best of my knowledge and belief. Vice President	5/24/01
SKINATURE TITLE Vice Pres	TELEPHONE NO. 915-683-334
TYPE OR PRINT NAME S.K. Lawlis	танты
(This space for State Use) The Stablished THUE Envir. En	5 Spcc, I DATE 6/5/2001
AUROVED BY Mare Stablished TILL Envir. Envir.	, ·

- 1. Bleed off existing gas pressure (900#).
- 2. MIRU WSU. Kill well with cut brine water.
- 3. Install & test BOP.
- 4. Dump 35' cement on CIBP @ 10,550'.
- 5. Perforate Strawn porosity 9,411'-9,698'.
- 6. TIH with packer on 2 7/8" L-80 tubing. Set packer @ 9,900'. Test BP to 3,000#.
- 7. Move and set packer @ 9,300'. Acidize & swab test Strawn zone 9,411'-9698'.
- 8. If Strawn zone is productive, set plug in packer. Release from packer. Spot 3 sx sand on top of packer.
- 9. Set cement retainer @ 4,850'. Squeeze cement casing leak @ 4,960'.
- 10. Set retainer @ 2,300'. Squeeze cement casing leak @ 2,835'.
- 11. Drill out cement & retainers. Pressure test casing.
- 12. Circulate sand off packer @ 9,300'.
- 13. Displace wellbore with treated water.
- 14. Latch onto packer & retrieve plug from packer.
- 15. Start production from Strawn zone.

1:00 M