

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

C/SF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

RECEIVED BY

DEC 12 1986

O. C. D.

2. NAME OF OPERATOR

Yates Drilling Company

3. ADDRESS OF OPERATOR

105 South 4th Street, Artesia, New Mexico 88210

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

5. LEASE DESIGNATION AND SERIAL NO.

NM-04219

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Anderson Federal

9. WELL NO.

6

10. FIELD AND POOL, OR WILDCAT

McMillan West

11. SEC., T. R., M., OR BLK. AND
SURVEY OR AREA

Section 11-20S-26E

12. COUNTY OR PARISH 13. STATE

Eddy

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Rig up pulling unit.
2. Disconnect pumping unit.
3. Pull rods out of hole and lay down.
4. Pull tubing and remove mud and/or gas anchor.
5. Run tubing with extra joints back in hole open ended and tag PBTD @ 645'.
6. Spot cement plug from 645'-346' in 5 1/2" casing. (approx. 35 sxs. Class "C" cement)
7. Pull tubing to 250' and wait 3 hours on cement.
8. Add tubing to tag cement plug.
 - A. If cement has fallen below 360' then spot additional plug.
 - B. If cement is at or above 360' then go to step #9.
9. Circulate hole from top of cement plug with salt water gel. (25# gel/barrel brine)
10. Pull tubing out of hole and lay down.
11. Spot cement surface plug from 90'-0' in 5 1/2" casing with last three joints of tubing. (approx. 10 sxs. Class "C" cement)
12. Pull remaining tubing and top hole off with cement.
13. Erect surface marker and/or clean surface as required to meet Bureau of Reclamation and Bureau of Land Management requirements.

18. I hereby certify that the foregoing is true and correct

SIGNED

John Rhoden

TITLE Engineer

DATE

12-5-86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

12-5-86

*See Instructions on Reverse Side