

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

L. C. 029096(a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Colglazier

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Barber

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

20 - 20S - 30E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Harris G. Eastham, Jr.

3. ADDRESS OF OPERATOR

% K. Yarbrough, Box 1471, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface1980' from the south line and 1980' from the east line of
Sec. 20, T20S, R30E.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3247

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

X

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Permanently abandon well as follows:

1. Spot cement plug from T.D. to 1400'. Set cement from T.D. to 1120'.
2. Cut and pull 7" csg. @ 550' or lower. Cut 7" @ 510', wouldn't come, cut at 510' and pulled.
3. Spot solid cement plug from 1250' to 350'. (Cement to be salt saturated). Cemented from just above 1120' to 228' from surface.
4. Cut and pull as much 8-5/8" csg. as practical. Pulled 51' of 8-5/8".
5. Spot 100' cement plug in and out 8-5/8" stub. Cemented solid from above 1120' to 228' of surface.
6. Spot 20' cement plug at surface. Spotted cement at surface and set marker.
7. Heavy mud to be placed between cement plugs.
8. Install regulation marker.
9. Maintained circulation to the surface on both jobs.

Above work is in conformance with Oil & Potash regulations.

RECEIVED

JUN 13 1980

O. C. D.

ARTESIA, OFFICE

18. I hereby certify that the foregoing is true and correct.

SIGNED

TITLE Agent

DATE Jan. 4, 1968

(This space for Federal or State office use)

(Sgd.) GEORGE H. STEWART

ACTING DISTRICT ENGINEER

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side