Form 9-331 (May 1963) Form approved. Budget Bureau No. 42-R1424. UN ED STATES SUBMIT IN TRIP. 'TH' DEPARTMENT OF THE INTERIOR (Other Instructions of re-5. LEASE DESIGNATION AND BERIAL NO. GEOLOGICAL SURVEY NM-0338758 6. IF INDIAN, ALLOTTER OR TRIBE NAME SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals.) UNIT AGREEMENT NAME 1. RECEIVE WELL GAS WELL |X| /Springs Unit Federal OTHER 8. BARM OR LEASE NAME 2. NAME OF OPERATOR DEC 4 1974 Gulf Oil Corporation 9. WELL NO. 3. ADDRESS OF OPERATOR Box 670, Hobbs, New Mexico 88240 0.c.cLOCATION OF WELL (Report location clearly and in accordance with any State requiremental, DFFICE See also space 17 below.) 10. FIELD AND POOL, OR WILDCAT Springs Upper Penn
11. SEC., T., B., M., OR BLE. AND
SURVEY OR AREA At surface 1980' FN & EL, Section 34, 20-S, 26-E Sec 34, 20-S, 26-E 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 12. COUNTY OR PARISH 13. STATE 14. PERMIT NO. 3221' GL Eddy New Mexico 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSECUENT REPORT OF : REPAIRING WELL PULL OR ALTER CASING TEST WATER SHUT-OFF WATER SHUT-OFF ALTERING CASING FRACTURE TREAT MULTIPLE COMPLETE FRACTURE TREATMENT ABANDONMENT* SHOOTING OR ACIDIZING SHOOT OR ACIDIZE ARANDON® REPAIR WELL CHANGE PLANS (Norm: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) (Other) Plug and Abandon 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* 8800' TD. 8747' PB. Pull producing equipment. Set CI BP on top of Baker Model D packer at 7950'. Circulate hole with abandonment mud. Spot 35' cement plug on top of BP. Cut and recover 5-1/2" casing at free point, which should be around 6600'. Spot 100' cement plug across 5-1/2" casing stub. Spot 100' cement plug from 5050' to 4950', across 1st Bone Springs at 5020'. Spot 100' cement plug from 2775' to 2675', across 8-5/8" casing shoe at 2714'. Spot cement plug from 50' to surface. Install dry hole marker and clean location. MONEY ENGLISH U. S. GEOLOGICAL SURVEY ARTESIA, NEW MEXICO 18. I hereby certify the three foregoing is true and correct DATE November 25, 1974 Area Engineer SIGNED TITLE . (This space for Federal or State office use) APPROVED SUBJECT TO POSSIBLE ADDITIONAL A DOMESTIONS OF APPROVAL, DATE REQUIREMENT THAT FAD AND OR ROAD WF ANY: F RITHLD AND SEEDED *See Instructions on Reverse Side

CONTACT THIS OFFICE REGARDING ABOVE

ACTING DISTRICT ENGINEER