

NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SAN ANTONIO	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

APR 4 1968

D. C. C.
ARTS & CRAFTS OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-11555
7. Unit Agreement Name
8. Farm or Lease Name Big Eddy Unit
9. Well No. 17
10. Field and Pool, or Wildcat Wildcat
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Cities Service Oil Company (Agent for Perry R. Bass)
3. Address of Operator Box 69 - Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER B 660 FEET FROM THE North LINE AND 1980 FEET FROM East LINE, SECTION 2 TOWNSHIP 21S RANGE 29E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3387 DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

We propose to plug and abandon the above well in the following manner:

1. Pull tubing and load hole with mud laden fluid.
2. Set latch type DR plug in Model D packer @ 11250, and dump 2 sacks cement on top of packer from 11250-11233.
3. Cut and pull 5½" casing. Approximate recovery 8400'.
4. Set 50 sack cement plug @ approx. 8450-8350. (Half in and half out of 5½" casing stub).
5. Set 50 sack cement plug on top of first Bone Springs sand @ approx. 7450-7350.
6. Set 50 sack cement plug on top of Bone Springs Lime @ approximate 6450-6350.
7. Set 50 sack cement plug in the Delaware Sand section @ approximate 5450-5350.
8. Set 50 sack cement @ approx. 4050-3950. (Half in and half out of 9 5/8" csg. set @ 4000).
9. Set 320 sack cement plug (inside 9 5/8" casing) across entire salt section @ approx. 1445-658.
10. Set 10 sack cement surface plug @ approx. 30-0 with a 4" pipe marker extending 4' above ground to indicate a dry hole.
11. Location will be cleared of all debris, pits and cellar will be filled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE **District Clerk** DATE **4-3-68**

APPROVED BY W. A. Gussitt TITLE **OIL AND GAS INSPECTOR** DATE _____

CONDITIONS OF APPROVAL, IF ANY: