

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE  
(Other instructions on reverse side)Form Approved  
Budget Bureau No. 42 R1424  
6. LEASE DESIGNATION AND SERIAL NO.

NM-0338754

8. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Springs Unit Federal

8. FARM OR LEASE NAME

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Springs Upper Penn

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec 34, 20-S, 26-E

12. COUNTY OR PARISH 13. STATE

Eddy

New Mexico

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☒ OTHER

RECEIVED

2. NAME OF OPERATOR

Gulf Oil Corporation

DEC 4 1974

3. ADDRESS OF OPERATOR

Box 670, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

ARTS

1980' FSL &amp; 660' FWL, Section 34, 20-S, 26-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3271' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Plug and Abandon

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

8140' TD, 8118' PB.

Pull producing equipment. Set CI BP on top of Guiberson Type A packer at 8020'. Circulate hole with abandonment mud. Spot 35' cement plug on top of BP. Cut and recover 5-1/2" casing from free point, which should be around 4100'. Spot 100' cement plug from 5450' to 5350', across 5-1/2" DV tool at 5403'. Spot 100' cement plug across 5-1/2" casing stub. Spot 100' cement plug across 8-5/8" shoe at 2698' and 50' cement plug from 50' to surface. Install dry hole marker and clean location.

RECEIVED  
NOV 27 1974  
U.S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Area Engineer

DATE November 25, 1974

(This space for Federal or State office use)

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED SUBJECT TO POSSIBLE ADDITIONAL  
REQUIREMENT THAT PAD AND/OR ROAD  
BE R\*See Instructions on Reverse Side

CONTACT THIS OFFICE REGARDING ABOVE

RECEIVED  
DEC 3 1974H. L. BEEKMAN  
DISTRICT ENGINEER