

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Barbara Fasken

3. Address and Telephone No.

303 W. Wall, Suite 1900

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

840' FSL, 935' FWL, Sec. 9, T21S, R24E

FORM APPROVED

Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM0247971

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

Comm. No. SW-421

8. Well Name and No.

Skelly Federal Com. No. 1

9. API Well No.

30-015-20075

10. Field and Pool, or Exploratory Area

Indian Basin (Morrow)

11. County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☒ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

Expected Start Date: 9-28-92

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Objective: Plug back from Morrow perfs 9784'-9805', 9887'-9947' and test Strawn.

- 1) POW with tubing and packer.
- 2) Run and set 4-1/2" CIBP by wireline @ 9750'. Top Morrow @ 9783'. Dump 3 sacks Class "H" cement on CIBP w/bailer. Run GR/CCL logs for correlation.
- 3) Set 4-1/2" production/treating packer and 2" tubing at 8550'.
- 4) Perforate Strawn interval 9082-88' through tubing. Swab test, acidize if necessary, and evaluate zone.
- 5) If zone 9082-88' is non-commercial, POW w/tubing and packer. Set CIBP by wireline @ 8900'. Dump 1 sack Class "H" cement on CIBP w/bailer.
- 6) Set 4-1/2" packer and 2" tubing at 8550'.
- 7) Perforate Strawn 8659-67'. Swab test, acidize and evaluate zone.
- 8) If zone 8659-67' is non-commercial, reset packer @ 8700'.
- 9) Perforate Strawn 8755-63'. Swab test, acidize and evaluate zone.
- 10) Return well to production or evaluate for further action.

14. I hereby certify that the foregoing is true and correct

Signed

Carl Brown

Title

Petroleum Engineer

Date

9-25-92

(This space for Federal or State office use)

Approved by

Title

Date

10/6/92

Conditions of approval, if any: