

**Levers Federal #1**  
1594' FNL & 660' FWL, Sec. 2-T21S-R25E  
Eddy County, New Mexico

**Procedure to Test Well for Casing Integrity**

1. Contact BLM in Carlsbad at 505-887-6544 48 hours before beginning procedure.
2. MIRU WU. RU H2S monitoring and air equipment.
3. Load tubing with produced water. ND WH and NU BOP.
4. PU on 3-1/2" tubing and pull out of packer. Well files indicate Model G locator seal assembly in well so straight pull should remove seal assembly from packer. POH, LD 3-1/2" tubing.
5. RIH with CICR on 2-7/8" 6.5# J-55 work string. Set retainer at 7775'. Unsting from retainer. Load hole.
6. Close BOP's and pressure casing to 600 psi. Use a chart recording device to record pressure. After 30 minutes release pressure. Maximum bleed off is 10% in 30 minutes.
7. Circulate biocide around wellbore. POH, LD work string.
8. ND BOP and NU WH.
9. Send chart to Midland for filing with BLM.

Note: If well fails MIT, an AFE to P&A and a sundry notice detailing P&A will be prepared immediately for filing with BLM.

  
\_\_\_\_\_  
Doug Keathley  
Area Supervisor