

N.M.O.C.D. COPY
UNIT STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other Instructions on
reverse side)Form approved.
Budget Bureau No. 42-R1424.

c/sf

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. NM 7068
2. NAME OF OPERATOR MONSANTO COMPANY ✓		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 1330 Midland NBT, Midland, Texas 79701		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1600' FNL & 1980' FEL, Sec. 3, T-21S, R-27E		8. FARM OR LEASE NAME Miller Federal
14. PERMIT NO.		9. WELL NO. 1
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3199 DF		10. FIELD AND POOL, OR WILDCAT Burton Flat-Morrow Atoka
O.C.D. ARTESIA, OFFICE		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 3- 21S-27E
		12. COUNTY OR PARISH Eddy, NM
		13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:


WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set CIBP at 11,002' dump 5 sacks cement. 1/9/81
2. Set CIBP at 10,300'. 1/9/81
3. Spot 15 sack plug at 10,300'. 1/12/81
4. Shot 5½" casing at 8923'.
5. Spot 100 sacks at 8998' across stub. 1/21/81 - Tag plug 8623'
6. Spot 40 sacks at 7000'. 1/23/81
7. Spot 40 sacks at 5160'. 1/23/81
8. Set 9 5/8" Retainer at 2625', squeeze 50 sacks under, 10 sacks on top. 1/24/81
9. Set 15 sacks at surface. 1/24/81

Hole was circulated with mud prior to setting plugs.
Maker was installed at well.



18. I hereby certify that the foregoing is true and correct

SIGNED Nesse L. HobbsTITLE Reg. Prod. Mgr. Engr.DATE 3/6/81

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE 11-22-88

*See Instructions on Reverse Side

Post IO-2
12-2-88
P4A