

DISTRIBUTION		
SANTA FE	1	
FILE	1	
U.S.G.S.		
LAND OFFICE		
DEPT OF		
OR		X

# **RECEIVED** NEW MEXICO OIL CONSERVATION COMMISSION

**MAR 20 1975**

**O. C. C.  
ARTESIA, OFFICE**

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

## **SUNDRY NOTICES AND REPORTS ON WELLS** (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

☐ OIL WELL ☒ GAS WELL ☐ OTHER-

Name of Operator  
**Hillin Production Company**

Address of Operator  
**Box 152, Odessa, Texas 79760**

Location of Well  
UNIT LETTER **K** **1980** FEET FROM THE **West** LINE AND **1980** FEET FROM  
THE **South** LINE, SECTION **2** TOWNSHIP **20S** RANGE **28E** NMPM.

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.  
**K5090**

7. Unit Agreement Name  
**K**

8. Farm or Lease Name  
**JCW State Com**

9. Well No.  
**2**

10. Field and Pool, or Wildcat  
**Winchester-Morrow**

12. County  
**Eddy**

15. Elevation (Show whether DF, RT, GR, etc.)

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated dates of completion, if any proposed work) SEE RULE 1103.

Pull tubing and packer from well bore. Run cast iron Bridge Plug on wire line and set at 9100' and dump 20' of cement on Bridge Plug with dump bailer. Displace hole with mud laden fluid. Cut 5½ csg. at free point. Pull and lay down csg. Run tubing to 50' into 5½ stub. Pump 35 sx cement plug. Pull tubing to 5700'. Pump 35 sx plug. Pull tubing to 4100'. Pump 35 sx plug. Pull tubing to 3000' and pump 35 sx plug. Pull out of hole with tubing. Cut 8 5/8 csg. at free point. Pull and lay down 8 5/8 csg. Run tubing 50' inside 8 5/8 stub. Pump 50 sx plug. Pull tubing to 400' pump 65 sx plug. Pull out of hole, place 10 sx surface plug and dry hole marker.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *H.C. Boaling* TITLE Agent Date: 3-18-75

APPROVED BY *W.A. Gressett* TITLE SUPERVISOR, DISTRICT II DATE MAR 20 1975

CONDITIONS OF APPROVAL, IF ANY:  
as noted above

Notify N.M.O.C.C. in sufficient time to witness  
Plugging