

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions
reverse side)Copy to SF
Farm approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR Cities Service Oil Company		8. FARM OR LEASE NAME Elizondo Federal A	
3. ADDRESS OF OPERATOR Box 1919 - Midland, Texas 79701		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State regulations. See also space 17 below.) At surface 660' FNL & 1980' FWL of Sec. 28-T21S-R27E, Eddy Co., New Mexico		10. FIELD AND POOL, OR WILDCAT Burton Flat Morrow	
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 28-T21S-R27E	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3211' GR		12. COUNTY OR PARISH Eddy	
		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data:

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

T.D. 11673' Shale PBTD 11638'. We propose to plug and abandon this well in the following manner:

1. MIRU casing puller, release packer set @ 11026', load hole with mud laden fluid and pull tubing and packer.
2. Set a CIBP @ 11050' and dump 4 sacks of cement on top of CIBP @ approx. 11050 - 11015' to plug off Morrow perms @ 11262 - 11597'.
3. Cut off 5-1/2" casing @ approx. 8600' and pull casing out of hole.
4. Run open ended 2-7/8" OP tubing in hole and displace a 60 sack cement plug @ approx. 8675 - 8525' (1/2 in and 1/2 out of 5-1/2" casing stub @ 8600').
5. Displace a 75 sack cement plug across top of 2nd Bone Springs Sand @ approx. 7185 - 7035'.
6. Displace a 75 sack cement plug across top of 1st Bone Springs Sand @ approx. 6500 - 6350'.
7. Displace a 75 sack cement plug across top of Bone Springs @ approx. 5175 - 5025'.
8. Displace a 50 sack cement plug @ approx. 3150 - 3050' (1/2 in and 1/2 out of 10-3/4" casing shoe @ 3100').
9. Spot a 15 sack cement surface plug @ approx. 50 - 0' and install a 4" dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Region Operation Manager

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side