

UNITED STATES OF AMERICA
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

REMIT IN TRIPLE
(Copy instructions
verse side)

Form approved,
Budget Bureau No. 42-R1424.

6. LEASE DESIGNATION AND SERIAL NO.

NM 6008-A

8. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Loafer Draw Unit X

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Wildcat - Morrow

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 17-T21S-R22E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

1.

OIL
WELL

☐

GAS
WELL

☐

OTHER Dry Hole

2. NAME OF OPERATOR

Cities Service Oil Company ✓

3. ADDRESS OF OPERATOR

Box 1919 - Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

1980' FSL & 1980' FEL of Section 17, T21S, R22E
Eddy County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4463' GR

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was drilled to a total depth of 8873, tested in the Morrow and found dry, plugged back to 7490', tested in the Wolfcamp and found dry, and has been temporarily abandoned since January 30, 1974. We now wish to plug and abandon this well as follows:

- (1) MIRU double derrick unit - install Blow out preventer - load hole w/9# brine.
- (2) Release pkr, set bottom of tbg at 7485' & circ. hole with heavy mud (10# PPG) - POOH with tubing & packer.
- (3) Rig in with dump bailer & dump 5 sacks (50') on tope of sand & CIBP at 7490'.
- (4) Rig in hole with CIBP on wire line & set at approximately 6500' - dump 5 sacks cement (50') on top CIBP with dump bailer.
- (5) MIRU casing pullers - weld on lift nipple - reclaim well head - shoot off casing (15.5# N-80) at approximately 6100'
- (6) Rig in hole w/2-7/8" tbg open ended to a point 50' inside 5 1/2" casing - spot 40 sacks (100') cement plug 1/2" in & 1/2" out of 5 1/2" casing stub (approx. 6150' - 6050').
- (7) Set 40 sack (100') cement plugs from 4900'-5000' across top of Wolfcamp, from 3650'-3750' across top of Abo, from 2250'-2350' across top of Clearfork, from 1730'-1630' 1/2" in & 1/2" out of 9-5/8" casing shoe; and set 20 sack (50') cement plug in top of 9-5/8" casing.
- (8) Install 4" dry hole marker.

(We are attaching a copy of the completion schematic and a copy of the P & A schematic.)

18. I hereby certify that the foregoing is true and correct

SIGNED

E. Spiller

TITLE

Region Operation Manager

DATE

October 3, 1974

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

OCT - 9 1974

R. L. BEECHER
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

RECEIVED
OCT 10 1974
D.C.C.
ARTESIA, OFFICE