

DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug a well or to create a reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

JUN 04 1984

O. C. D.
ARTESIA, OFFICE

5. LEASE DESIGNATION AND SERIAL NO.

NM 0455458

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal DC

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Undesignated

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Unit L, Sec. 29-T20S-R28E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3239' GR

12. COUNTY OR PARISH

Eddy

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☒
☒
☐

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other) Recomplete, Perforate, Treat

☒

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Moved in and rigged up unit. POOH w/tubing and packer. Ran RTTS and squeezed Atoka perms 10624-34' w/75 sacks Class "H" cement to 4500 psi. POOH w/RTTS. Ran bit, scraper and drill collars to bottom. Drilled out cement and tested to 2000 psi. POOH with bit and scraper. Released RBP and POOH. RIH w/bit, scraper and drill collars. Drilled out cement retainer at 11180' (set retainer at 11180' in 1978) and CIBP at 11220' (CIBP set at 11220' in 1978). Cleaned out well to 11361. POOH w/bit, scraper and drill collars. Set cement retainer at 11300'. Ran tubing and stinger. Squeezed perms 11350-60' w/50 sacks Class "H" cement to 5000 psi w/35 sacks in formation. POOH. RIH and set packer at 11225'. Test perms 11258-76'. Acidized perms 11258-76' w/1000 gallons 7½% Morflow acid, N2 and ball sealers. Flowed well back. Swabbed dry. Stabilized at 40# on 1/8" choke. Loaded tubing, released packer. POOH. Ran tubing and RBP set @11250'. WIH and perforated 11227-40' w/10 .50" holes as follows: 11227, 28, 29, 32, 33, 34, 37, 38, 39, and 40'. RIH w/tubing and packer. Acidized perms 11227-40' w/1500 gallons 7½% Morflow acid and N2. Zones communicated. Released packer and RBP. RBP reset at 11292'. Packer set at 11085'. Well stabilized at 100 psi on 1/8" choke = 40 mcf/gpd. Well producing from Morrow perforations 11131-49'; 11227-40'; 11258-76'. Work began 4-14-84. Work completed 5-14-84.

ACCEPTED FOR RECORD

I hereby certify that the foregoing is true and correct

SIGNED

TITLE Production Supervisor

DATE 5-18-84

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

NEW MEXICO

*See Instructions on Reverse Side