N.M.O.O.D. OUPY Form 9-331 (May 1963) Form approved. Budget Bureau No. 42-R1424. UN TED STATES ATE* IN TRIE DEPARTME OF THE INTERIOR (Other instructions verse side) 5. LEASE DESIGNATION AND SERIAL NO. GEOLOGICAL SURVEY NM 0112134 6. IF INDIAN, ALLOTTEE OR TRIBE NAME SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals.) 7. WNIT AGREEMENT NAME RECEIVED X OTHER 2. NAME OF OPERATOR S. FARM OR LEASE NAME DEC 1 9 1980 MONSANTO COMPANY Round Mountain 3. ADDRESS OF OPERATOR 9. WELL NO. O. C. D. 1330 Midland NBT, Midland, Tx 79701 LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)

At surface 10. FIELD AND POOL, OR WILDCAT Wildest Morrow 11. SEC., T., R., M., OR BLK. AND 1980 FNL & 1980 FWL, Section 28, T-21-S, R-25-E SURVEY OR AREA Sec. 28, T-21-S, R-2 12. COUNTY OR PARISH | 13. STATE R-25-E 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 14. PERMIT NO. 3528 Ground N.M16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: PULL OR ALTER CASING WATER SHUT-OFF REPAIRING WELL TEST WATER SHUT-OFF FRACTURE TREATMENT ALTERING CASING MULTIPLE COMPLETE FRACTURE TREAT ABANDONMENT* SHOOTING OR ACIDIZING SHOOT OR ACIDIZE REPAIR WELL CHANGE PLANS (Other) (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) (Other) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* Est. starting date - November, 1980. Set Cast Iron Bridge plug at 10325'. Set 50' cement on top. Cut 5 1/2" csg. at 8200'. Pull casing. Circulate hole with 9.5 ppg. brine. Set 150' plug 75' in and 75' out of 5 1/2" cut stub.

Set 150' plug above Wolfcamp top at 7642'.

Set 150' plug from 5750' to 5900'.

Set 100' plug from 3887' to 3987'.

Set 100'plug at 9 5/8" casing shoe at 2445' from 2495' to 2395'.

Set 25 Sx. plug at surface. Install marker.

RECEIVED

	OCT 23 U.S. GEOLOGIC ARTESIA, NE	2 3 1980 DGICAL SURVEY NEW MEXICO	
18. I hereby certify that the foregoing is true and correct SIGNED	TITLE Regional Prod. Mgr.	DATE .	10/22/80
(This space for Federal or State office use) (Orig. Sgd.) PETER W. CHESTER APPROVED BY CONDITIONS OF APPROVAL, IF ANY:	TITLE ACTING DISTRICT ENGINEER	DATE _	DEC 1 7 1980
*Se	e Instructions on Reverse Side		