2		
NO. OF COPIES RECE DISTRIBUTION SANTA FE FILE U.S.G.S.	MECE/VEI)	Form C-103 Supersedes Old C-102 and C-103 Effective 1-1-65
LAND OFFICE OPERATOR	O. C. D. ARTESIA, OFFICE	State X Fee 5. State Oil & Gas Lease No. LG 794
	SUNDRY NOTICES AND REPORTS ON WELLS THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL 2. Name of Operator	GAS WELL X OTHER-	7. Unit Agreement Name
1	cvice Company /	8. Farm or Lease Name State CT Com
3. Address of Operator		9. Well No.
	1919 - Midland, Texas 79702	1
4. Location of Well UNIT LETTER	I 1980 South 660	10. Field and Pool, or Wildcat // Burton Flat Morro
East	LINE, SECTION 16 TOWNSHIP RANGE NMPM.	
	15. Elevation (Show whether DF, RT, GR, etc.) 3253 GR	12. County Eddy
Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:		
PERFORM REMEDIAL WE TEMPORARILY ABANDON PULL OR ALTER CASING	COMMENCE DRILLING OPNS.	ALTERING CASING PLUG AND ABANDONMENT
OTHER		
17. Describe Proposed work) SEE RULE	d or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including 1103.	estimated date of starting any proposed
	,425' P.B.T.D. 11075'. It is proposed to plug ar llowing manner:	nd abandon this well
1. 2. 3.	hole with mud laden fluid. Pull tubing and packer. Set a CIBP @ 10875' and dump 35' of cement on t	-
4.	Morrow Perfs @ 10929 - 10942'. Set a CIBP @ 10600' and dump 35' of cement on t Atoka Perfs @ 10635 - 10644'.	cop to plug off the
5.		
6.	Set a CIBP @ 9450' and dump 35' of cement on to Wolfcamp Perfs @ 9499 - 9509'.	op to plug off the
7.	Determine the free point of the 5-1/2" casing Survey @ 7800'). Shoot 5-1/2" casing off and p	

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief. Feb. 17, 1981 Region Operations Mgr. FEB 2 5 1981 TITLE OIL AND GAS INSPECTOR

Go in hole with 2-7/8" OD tubing and spot a 100' cement plug, half in and half out on 5-1/2" casing stub. $t \leftarrow 9$

CONDITIONS OF APPROVAL, IF ANY: * AS Noted on Buck

Notify N.M.O.O.O. in sufficient time to witness Plugging

(CONTINUED ON BACK)

- Pull tubing to 3050' and spot a 100' cement plug @ 2950 3050', half in and half out of 8-5/8" casing shoe @ 3000'. + $\tau \sim \gamma$ Spot a 10 sack cement surface plug a 30 0'. Remove wellhead, clean location and install 4" dry hole marker.
- 11.

spot a 100' cement plug from 6,530-6,630' spot a 100' Cement plug from 5,010'-5,110' * spot a 100' Cement plug from 600-700'

Pull tubing to 3050' and spot a 100' cement plug @ 2950 - 3050', half in and half out of 8-5/8" casing shoe @ 3000'. + Tag

Spot a 10 sack cement surface plug a 30 - 0'.

Remove wellhead, clean location and install 4" dry hole marker.

* Spot a 100' Cement plug from 6,530'-6,630' Spot a 100' Cement plug from 5010'-5,110' 'Spot a 100' Cement plug from 600'-700'