

8. RIH with open ended tbg & loaded hole with mud laden fluid.
9. Spotted a 35 sack cement plug @ 7787 - 7673', $\frac{1}{2}$ in and $\frac{1}{2}$ out of 5 $\frac{1}{2}$ " csg stub @ 7,737'. RIH with open ended tbg & tagged top of cement plug @ 7,673'. LD tbg to 6,635'.
10. Spotted a 40 sack cement plug @ 6635 - 6535'. LD tubing to 5111'.
11. Spotted a 40 sack cement plug @ 5111 - 5011'. LD tubing to 3041'.
12. Spotted a 50 sack cement plug @ 3041 - 2941', $\frac{1}{2}$ in and $\frac{1}{2}$ out of 8-5/8" casing shoe @ 3000'. RIH with open ended tbg & tagged top of cement plug @ 2941'. LD tubing to 650'.
13. Spotted a 50 sack cement plug @ 650 - 550'. LD all of tubing.
14. Cleaned cellar, cut off well head & set a 10 sack cement surface plug @ 50 - bottom of cellar. Installed a 4" dry hole marker to designate a plugged and abandoned location.

Mr. Mike Williams w/NMOCD witnessed plugging job.