

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.  
30-015-21859

5. Indicate Type of Lease  
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

Jones Com

1. Type of Well:  
OIL WELL ☐ GAS WELL ☒ OTHER

2. Name of Operator  
Hallwood Petroleum, Inc. ✓

8. Well No.  
1

3. Address of Operator  
P.O. Box 378111 Denver, CO 82037

9. Pool name or Wildcat  
Revelation *Morrow*

4. Well Location  
Unit Letter I : 1980 Feet From The South Line and 660 Feet From The East Line  
Section 9 Township 22S Range 25E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
3520 GR, 3533 KB

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Please see attached proposed plugging procedure, and  
copy of BLM for 3160-5.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Debi Sheely TITLE Sr. Engineering Tech DATE July 31, 1992

TYPE OR PRINT NAME Debi Sheely TELEPHONE NO. (303)850-6207

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

JONES COM #1  
UNIT I SECTION 9 T228 R. 3E  
EDDY COUNTY, NEW MEXICO

**PROPOSED PLUGGING PROCEDURE**

1. MIRUSU, ND tree and NU BOP's.
2. Release packer and TOH with tubing and packer.
3. Bail 35 feet of cement on plug and packer over Morrow at 10,072'.
4. Run a 7" CIBP on wireline to 8,750', set and cap with 35' feet of cement. This plug will cover the top of line and the Strawn. Note: Fill intervals between plugs with minimum 9.0 ppg, 36 vis plug mud.
5. Pick-up on 7" casing, stretch or freepoint and cut casing as deep as practical (hopefully between 4,500 - 5,000'). TOOH laying down casing.
6. RIH with tubing, tag casing stub and pump 75 sxs class "C" stub plug. WOC and tag plug.
7. RIH with tubing to 2,359' (50' below surface shoe) and pump 100 foot (minimum) surface pipe shoe plug. WOC and tag plug.
8. TOH and pump cement from 400 feet to surface in 9 5/8" casing.
9. Cut off 9 5/8" casing 4 feet below ground, weld on I.D. cap.
10. Install dry hole marker post.
11. Restore road and location.