| Chokember (1983) Chokem | Expires August 32 1085 LEASE DESIGNATION AND BERIAL NMNM25348 |
|--|---|
| SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.) | IF INDIAN, ALLOTTEE OR TRIBE NAME |
| OIL GAS WELL X OTHER RECEIVED 7 | . UNIT AGREEMENT NAME |
| Hallwood Petroleum, Inc. / 488.4932 | Federal RV 10 |
| P.O. Box 378111 Denver, CO 80237 | Wall No. |
| At surface | Revelation (Morrow) |
| Unit E 1980' FNL 915' FWL | 1. SSC., T., A., M., OR BLK. AND SURVEY OR ARM |
| 14. PERMIT NO. 15 ELEVATIONS (Show whether DF, RT, GR, etc.) 1 3,512 GL | Section 10 T22S R25E 2. COUNTY OR PARISH 13. STATE Eddy NM |
| Check Appropriate Box To Indicase Nature of Notice, Report, or Oth | er Data |
| | I EMPORT OF: |
| TEST WATER SHUT-OFF PULL OR ALTER UNSING WATER SHUT-OFF FRACTURE TREAT SHOUT OR ACIDIZE REPAIR WELL CHANGE PLANT WATER SHUT-OFF WATER SHUT-OFF FRACTURE TREATMENT XXX SHOOTING OR ACIDIZING | ALTERING CABING ARANDONMENT* |
| | multiple completion on Well |
| PLEASE SEE ATTACHED PROPOSED PLUGGING PROCEDURE. | |
| | |
| 16. I hereby certify that the foregoing is true and correct | |

*See Instructions on Reverse Side

DATE _

TITLE .

Federal RV 10 #1
Section 10 T22S R25E
Eddy County, New Mexico

4+ R | 1 1992 D. C. O.

PROPOSED PLUGGING PROCEDURE:

- 1. MIRUSU, pull rods and pump, ND tree and NU BOP's.
- 2. Release anchor and TOH with tubing and packer.
- 3. Run a 5-1/2" CIBP on wireline to 10,100', set and cap with 35 feet of cement.
- 4. Run a 5-1/2" CIBP on wireline to 8,650', set and cap with 35' feet of cement. This plug will cover the DV tool at 8,718'. NOTE: Fill intervals between plugs with minimum 9.0 ppg, 36 vis. plug mud.
- 5. Pick-up on 5-1/2" casing, stretch or freepoint and cut casing as deep as practical (hopefully between 5,000-6,000'). TOOH laying down casing.
- 6. RIH with tubing to 2,325' (50' below surface shoe) and pump 100 foot (minimum) surface pipe shoe plug.
- 7. TOH and pump cement from 400 feet to surface in 9-5/8" casing.
- 8. Cut off 9-5/8" casing 4 feet below ground, weld on I.D. cap.
- 9. Install dry holemarker post.
- 10. Restore road and location.

DS\#17.pp