

Federal RV 10 #1
Section 10 T22S R25E
Eddy County, New Mexico

PROPOSED PLUGGING PROCEDURE:

1. MIRUSU, pull rods and pump, ND tree and NU BOP's.
2. Release anchor and TOH with tubing and packer.
3. Run a 5-1/2" CIBP on wireline to 10,100', set and cap with 35 feet of cement.
4. Run a 5-1/2" CIBP on wireline to 8,650', set and cap with 35' feet of cement. This plug will cover the DV tool at 8,718'.
NOTE: Fill intervals between plugs with minimum 9.0 ppg, 36 vis. plug mud.
5. Pick-up on 5-1/2" casing, stretch or freepoint and cut casing as deep as practical (hopefully between 5,000-6,000'). TOOH laying down casing.
6. RIH with tubing to 2,325' (50' below surface shoe) and pump 100 foot (minimum) surface pipe shoe plug.
7. TOH and pump cement from 400 feet to surface in 9-5/8" casing.
8. Cut off 9-5/8" casing 4 feet below ground, weld on I.D. cap.
9. Install dry holemarker post.
10. Restore road and location.

DS\#17.pp