

DRILLING PROGRAM

1. Drill 17 1/2" hole to 600' and set 13 3/8", 48#, S.T. & C. surface casing. Cement with 600 sx. Class "C". Cement will be circulated.
2. Drill 12 1/4" hole from 600' to 2,400'. Set 2,400' of 8 5/8", 32#, K-55, S.T. & C. casing, cemented with 1495 sx. Class "H" cement. Cement will be circulated.
3. Drill 7 7/8" hole from 2,400' to 11,500'. Run 11,500' of 4 1/2" 11.6#, N-80 casing, cemented with 800 sx. Class "C" cement, if completion attempt is warranted.

WELL SUPERVISION

Well site supervision will be maintained from surface to total depth. Samples will be caught, washed and sacked from below surface string at 600' to total depth at 10 foot intervals. Mud logging and gas detector unit will be operative from 2,500 feet to total depth. All significant shows of oil and/or gas will be drill stem tested. Mechanically recorded drilling time will be maintained from surface to total depth. Blowout preventor stack and casing head will be independently pressure tested before drilling into the Wolfcamp Formation. A daily check of the blowout preventor system will be made from 8,600 feet to total depth.