

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN THE ICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 3047

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Texas Hills "KM" Fed

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Unders. (Box Canyon)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREASec. 21-21S-21E
Unit H NMPM

12. COUNTY OR PARISH 13. STATE

Eddy

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different level.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL
WELL ☐GAS
WELL ☐

OTHER

Dry hole

AUG 23 1979

2. NAME OF OPERATOR

Yates Petroleum Corporation ✓

3. ADDRESS OF OPERATOR

207 South Fourth Street - Artesia, NM 88210

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

1836' FNL & 915' FEL of Section 21-21S-21E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4651' GR; 4664' KB

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well is non-commercial and we propose to plug and abandon as follows:
pull tubing, packer & RBP's from well. Set CIBP at about 4200' w/35
sacks cement on top. Shoot off 4-1/2" casing at about 3100' and spot
50' cement inside and 50' outside of casing stub. Spot 50' inside and
outside of 8-5/8" casing (1590-1490). Install dry hole marker and
clean up location.

RECEIVED

AUG 21 1979

U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

Eddie L. Hainford

TITLE

Engineer

DATE 8-20-79

(This space for Federal or State office use)

APPROVED BY

George H. Stewart

TITLE

ACTING CHIEF OF SURVEY

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side