

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

USA NM-12828

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

McClellan Fed. Com

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 11, T-22-S, R-24-E

12. COUNTY OR PARISH 13. STATE

Eddy

N.M.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

NOV 22 1978

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Dry Hole

2. NAME OF OPERATOR

Flag-Redfern Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 23 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State regulations.  
See also space 17 below.)  
At surface

960' FEL &amp; 2310' FSL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4016' G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☒CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)\*

Flag-Redfern Oil Company desires to plug and abandon this well because no productive zones were found. Below is our proposed plugging procedure to be done with the drilling rig still over the hole.

1. Run 4" Drill Pipe in mud-laden hole to 8000'.
2. Spot 150' cement plug from 8000' - 7850' using 50 sx of Class "H" cement.
3. Pull Drill Pipe up to 6500' and spot a 150' cement plug from 6500' - 6350' using 50 sx of Class "H" cement.
4. Pull Drill Pipe up to 5000' and spot a 100' cement plug from 5000' - 4900' using 35 sx of Class "H" cement.
5. Pull Drill Pipe up to 3100' and spot a 100' cement plug from 3100' - 3000' with 35 sx of Class "H" cement.
6. Pull Drill Pipe up to 1850' and spot a 100' cement plug from 1850' - 1750' using 35 sx of Class "H" cement.
7. Pull Drill Pipe up to 20' and circulate cement to the surface using 10 sx of Class "H" cement.
8. Pull Drill Pipe out of hole, Rig down and move off Drilling Rig.
9. Clean location as per instructions from the Bureau of Land Management.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Petroleum Engineer

DATE 9-26-78

(This space for Federal or State office use)

APPROVED BY

TITLE

ACTING DISTRICT ENGINEER

DATE NOV 21 1978

CONDITIONS OF APPROVAL, IF ANY: