

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate
(Other instructions on reverse side)

Copy to SF

Form Approved.
Budget Bureau No. 42-R1424.
LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Dry Hole		RECEIVED	
2. NAME OF OPERATOR Flag-Redfern Oil Company		NOV 22 1978	
3. ADDRESS OF OPERATOR P. O. Box 23 Midland, Texas 79702		O. C. C.	
4. LOCATION OF WELL (Report location clearly and in accordance with any State or Federal Survey or Area. See also space 17 below.) At surface 960' FEL & 2310' FSL		10. FIELD AND POOL, OR WILDCAT McKittrick Hills Upper Pe	
14. PERMIT NO. -----	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4016' G.L.	12. COUNTY OR PARISH Eddy	13. STATE N.M.
16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	(Other) <input type="checkbox"/>
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)			
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)			

Flag-Redfern Oil Company desires to plug and abandon this well because no productive zones were found. Below is our proposed plugging procedure to be done with the drilling rig still over the hole.

1. Run 4" Drill Pipe in mud-laden hole to 8000'.
2. Spot 150' cement plug from 8000' - 7850' using 50 sx of Class "H" cement.
3. Pull Drill Pipe up to 6500' and spot a 150' cement plug from 6500' - 6350' using 50 sx of Class "H" cement.
4. Pull Drill Pipe up to 5000' and spot a 100' cement plug from 5000' - 4900' using 35 sx of Class "H" cement.
5. Pull Drill Pipe up to 3100' and spot a 100' cement plug from 3100' - 3000' with 35 sx of Class "H" cement.
6. Pull Drill Pipe up to 1850' and spot a 100' cement plug from 1850' - 1750' using 35 sx of Class "H" cement.
7. Pull Drill Pipe up to 20' and circulate cement to the surface using 10 sx of Class "H" cement.
8. Pull Drill Pipe out of hole, Rig down and move off Drilling Rig.
9. Clean location as per instructions from the Bureau of Land Management.

18. I hereby certify that the foregoing is true and correct

SIGNED

James Kessler

TITLE

Petroleum Engineer

DATE

9-26-78

(This space for Federal or State office use)

APPROVED BY

James Kessler

TITLE

ACTING DISTRICT ENGINEER

DATE

NOV 21 1978