

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

NM-17200

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Southeast Indian Basin

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

und Indian Basin up to

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 23, T-22S, R-23E

12. COUNTY OR PARISH 13. STATE

Eddy

N. M.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1.

OIL ☐ GAS ☐  
WELL WELL OTHER Dry Hole

2. NAME OF OPERATOR

Harvey E. Yates Company ✓

3. ADDRESS OF OPERATOR

P. O. Box 1933, Roswell, N.M. 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*

See also space 17 below.)  
At surface

660' FNL &amp; 660' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4141.5' GL

16.

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

X

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.) \*

We plan to plug and abandon as follows:

- a) Set CIBP on wireline at 2610' and dump 25' cement on top.
- b) Shoot 5 1/2" casing at 2400' +. Pull & LD casing.
- c) Run 2 3/8" tubing OE 50' inside 5 1/2" casing stub at 2450'.
- d) Spot 220' cement plug. 50' up in 8 5/8" casing at 2238'.
- e) Place 15 Sx cement plug at surface. Weld plate on 8 5/8" casing & install dry hole marker. 10#/gal mud placed between plugs.

RECEIVED

NOV 13 1979

RECEIVED

NOV 13 1979

U.S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

*Paul Harder*

TITLE

Engineer

DATE 11-12-79

(This space for Federal or State office use)

APPROVED BY *George H. Stewart*

ACTING DISTRICT ENGINEER

TITLE

DATE

NOV 13 1979

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

1944

h