

RECEIVED BY

Form 9-331

Dec. 1973

JAN 2 - 1985

O. C. D.

ARTESIA OFFICE

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☐ gas well ☐ other Multiple

2. NAME OF OPERATOR
TXO Production Corp ✓

3. ADDRESS OF OPERATOR
900 Wilco Bldg Midland Tx 79701

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
1930 FNL & 1740 FEL
AT SURFACE:
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☐
(other) ☐

SUBSEQUENT REPORT OF:

☐
☐
☐
☒
☐
☐
☐
☐
☐

5. LEASE
NM 0354232

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Pioneer Fed Com

9. WELL NO.
1

10. FIELD OR WILDCAT NAME
Lahuerta (Wolfcamp) & Burton Flats (Morrow)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec 19, T21S R27E

12. COUNTY OR PARISH Eddy 13. STATE NM

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3183 GL

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

9-29-84 Well SI for pkr leakage test. Pressure communication found.
10-2-84 TOH w/X-over tool. Set "F" plug in nipple @11083'. Test selectively for leak. Leak determined to be in on-off tool. "F" profile plug left in nipple @11083' to eliminate communication.
10-30-84 TIH w/straight thru tool & load hole w/10# brine & KCL
10-31-84 TOH w/MCH pkr, tbg, & on off tool.
11-1-84 TIH testing tbg w/new on-off tool, and MCH pkr.
11-2,3-84 Attempt to retrieve "F" plug @11083' TOH w/plug
11-20-84 TOH W/ X-over. Set plug above MCH in nipple. Open sliding sleeve. Unload tbg & csg. TOH w/plug
11-21-84 Swab tby & csg dry
11-23-84 TIH w/straight-thru tool. Close sliding sleeve.

Subsurface Safety Valve: Manu. and Type N/A Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Kane Giffy TITLE Engineer DATE 11-26-84

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL IF ANY

TITLE

DATE

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.