Form 3160-5 (JUNE 1990)

## UNITED STATES DEPARTMENT OF THE INTERIOR

N.M. Oil
811 S. 1st
Artesia, Na

IS Division FORM APPROVED

CIST
------

0-2834 No. 1004-0135 **BUREAU OF LAND MANAGEMENT** 

SUNDRY NOTICES AND REPORTS ON WELLS		<ol><li>Lease Designation and Serial No. NM-17103</li></ol>	
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  Use "APPLICATION FOR PERMIT-" for such proposals		6. If Indian, Allottee or Tribe Name	
l. Type of Well	T IN TRIPLICATE	7. If Unit or CA, Agreement Designation	
Oil Gas  Well Well Other		8. Well Name and No.	
2. Name of Operator:  STRATA PRODUCTION COMPANY		Lee Federal #6	
3. Address and Telephone No. P. O. Box 1030		9. API Well No. 30-015-24891	
Roswell, New Mexico 88202-1030 505-622-1127		10. Field and Pool, or Exploratory Area Scanlon Delaware	
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  1875' FSL & 1765' FWL			
Section 25-20S-28E		11. County or Parish, State Eddy County, New Mexico	
12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA  TYPE OF SUBMISSION  TYPE OF ACTION			
V	77	CI CII	
Notice of Intent	Abandonment  Recompletion	Change of Plans  New Construction	
Subsequent Report	Plugging Back	Non-Routine Fracturing	
	Casing Repair	Water Shut-Off	
Final Abandonment Notice	Altering Casing	Conversion to Injection	
	OTHER	Dispose Water	
		(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	
3. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* Strata Production Company requests approval to plug and abandon the well within six months in the following manner:			
•	s, pump and production string.		
TIH with wireline 5 1/2     Circulate gelled space	2" CIBP. Set at 5400'. Cover perfs 5455'-f er.	5491'. Place 35' cement on top.	
3. Set 35 sack cement p	olug at 2565' to cover 8 5/8" casing shoe.		
4. Set 35 sack cement p	olut at 408' to cover 13 5/8" casing shoe.	TAS TAS	
5. Set 10' cement plug a	at surface.	KESIA (ESIA	
6. Set Dry Hole marker.	Remove surface equipment. Rip location	and reseed. (1919) Styles	
4. I hereby certify that the foregoing is true and correspond to the Signed that the foregoing is true and correspond to the signed to the sig	Communication Records Management	ger_Date 4/05/99	
(This space for Federal or State office use) Approved by (ORIG. SGD.) DAVID Conditions of approval, if any:	R. GLASS Title PETROLEUM ENGINE	ER NAY 0 4 1999	
* E			