

State of New Mexico  
Energy, Minerals and Natural Resources Department

DISTRICT I  
P.O. Box 1980, Hobbs NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL APIN NO.  
30-015-27728

5. Indicate Type of Lease  
State ☒ FEE ☐

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL ☐ GAS ☐  
WELL ☐ WELL ☒ OTHER ☐

2. Name of Operator  
Yates Petroleum Corporation

3. Address of Operator  
105 South 4th., Artesia, NM 88210

4. Well Location  
Unit Letter M : 660 Feet From The South Line and 660 Feet From The West Line  
Section 36 Township 21S Range 24E NMPM Eddy COUNTY

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
3814' GR

7. Lease Name or Unit Agreement Name

Indian Hill ARG State

8. Well No  
#1

9. Pool Name or Wildcat  
McKittrick Hills Strawn N.

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:  
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

SUBSEQUENT REPORT OF:  
REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon:

1. TIH with tubing and tag CIBP @ 9,990' load the hole with plugging mud. Spot a 5 sack Class C cement plug on top of the CIBP from 9,940 to 9,990'. Pulling tubing, up the hole and reverse circulate the tubing clean. Spot a 25 sack plug from 8760' to 9010' and WOC. Tag plug with tubing. POOH.
2. RU WL and cut 5.5" casing @ 7650' TOH with WL and attempt to pull casing. Cut casing at the the free point and pull casing.
3. TIH with tubing load hole with plugging mud and spot 50 sacks Class C cement plug from 7600' & 7700' across the 5.5" casing stub. Pull tubing up the hole into the intermediate casing and WOC.
4. Load the hole with plugging mud and spot 50 sacks Class C cement plug from 5600' to 5700' pull tubing up the hole to 3700'.
5. Load the hole with plugging mud spot 50 sacks Class C cement plug from 3600' to 3700'. Pull tubing up the hole to 1,700'.
6. Load the hole with plugging mud and spot 50 sacks Class C cement plug from 1,550' to 1,700'.

100' plug 7242-7342

CONTINUE ON NEXT PAGE

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Erma Vazquez TITLE Operations Technician DATE 28 January 2002

TYPE OR PRINT NAME Erma Vazquez TELEPHONE NO 505-748-1471

(This space for State Use)

APPROVED BY Field Rep ID DATE 28 January 2002

CONDITIONS OF APPROVAL, IF ANY: