

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I

P.O. Box 1980, Hobbs NM 88241-1980

DISTRICT II

P.O. Drawer DD, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

2040 Pacheco St.
Santa Fe, NM 87505

WELL API NO. 30-015-30020
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 22336
7. Lease Name or Unit Agreement Name CONOCO STATE
8. Well No. 3
9. Pool name or Wildcat DEVONIAN

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A "DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER DISPOSAL	
2. Name of Operator KERR MCGEE CORP.	
3. Address of Operator P.O. Box 2880, Dallas, TX 75221-2880	
4. Well Location Unit Letter <u>G</u> : <u>1650</u> Feet From The <u>NORTH</u> Line and <u>1650</u> Feet From The <u>EAST</u> Line Section <u>2</u> Township <u>22S</u> Range <u>23E</u> NMPM <u>EDDY</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3908' GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: UPGRADE TUBING ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SWELL DRILLED AS SALT WATER DISPOSAL WELL IN EDDY COUNTY, NEW MEXICO. ADMINISTRATIVE ORDER SWD-697 WAS APPROVED MARCH 9, 1998. SEE ATTACHMENTS

1. SI Well. MIRU workover rig. RD wellhead, RU BOPS. RU WL, RIH and set plug in 2.31 profile @ 10,100 ft., Approx. RD WL.
2. POOH and lat down 3 1/2" tubing.
3. RD 3 1/2" BOP, RU 40 1/2" BOPS. RIH W/4 1/2" tubing.
4. Latch ON-OFF tool at 10,100 ft.
5. RD BOPS, RU wellhead. RU WL. RIH, latch and pull plug in profile nipple at 10,100 ft. Approx. RIH W/Pressure bomb, obtain static BHP. POOH. RD WL.
6. Place well on injection.

WORK TO COMMENCE 5/10/99

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Edgar L. Perez TITLE PRORATION ANALYST DATE 4/14/99
TYPE OR PRINT NAME Edgar L. Perez TELEPHONE NO. 972 715-4603

(This space for State Use)

APPROVED BY ORIGINAL SIGNED BY TIM W. GUM TITLE DISTRICT II SUPERVISOR DATE 5-19-99
CONDITIONS OF APPROVAL, IF ANY:

