

LEVERS "2" FEDERAL # 1

1. Drill 25" hole to 40'. Set 40' of 20" conductor pipe and cement to surface with Redi-mix.
2. Drill 17½" hole to 500'. Run and set 500' of 13 3/8" H-40 48# ST&C casing. Cement with 650 Sx. Class "C" cement + 2% CaCl, circulate cement to surface.
3. Drill 12½" hole to 3000'. Run and set 3000' of 9 5/8" J-55 ST&C casing. Cement with 1000 Sx. Class "C" Halco Light, tail in with 500 Sx. Class "C" + 2% CaCl. Circulate cement to surface.
4. Drill 8 3/4" hole to 10,700'. Run and set 10,700' of 5½" N-80, P-110, LT&C 17# casing. Cement in two stages, 1st stage cement with DV tool at 7500' 600 Sx Halco Light + additives, tail in with 200 Sx. Class "H" + additives, 2nd stage with 750 Sx. Class "H" Halco Light + additives, tail in with 250 Sx. Class "H" + additives, top of cement 2800'.