

Submit 3 Copies To Appropriate District Office  
District I  
1625 N. French Rd., Hobbs, NM 87240  
District II  
811 South First, Artesia, NM 87210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources  
OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

Form C-103  
Revised March 25, 1999

WELL API NO.

30 - 015 - 30983

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

VA - 1337

7. Lease Name or Unit Agreement Name:

Sammy State

8. Well No.

1

9. Pool name or Wildcat

Wildcat Morrow

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

Nadel and Gussman Permian, L.L.C.

3. Address of Operator

601 N Marienfeld, Suite 508, Midland, Texas 79701

4. Well Location

Unit Letter E : 1650' feet from the North line and 660' feet from the West line

Section 15

Township 21-S

Range 25-E

NMPM

Eddy

County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

3414' GL, 3432' KB

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

1. MIRU. By wireline, run casing cutter and cut 5 1/2" casing at +/- 1500'. Pull and laydown casing.
2. TIH w/ work string open ended. Circulate casing with 10 PPG salt gel mud to surface.
3. Pump 30 sx "C" Neat plug on top of CIBP at 2125' and fill casing across intermediate shoe to 1900'.
4. Pump 30 sx "C" (100' +) plug across casing stub at 1500'. WOC and tag cement. 50' in + 50' wt 5 1/2" casing stub - TAG
5. Pump 30 sx "C" (100' +) plug across surface casing shoe from 455' to 355'. WOC and tag cement.
6. Spot 10 sx plug at surface. Cut-off wellhead and fill annulus with cement if necessary. Set standard 6' dry hole marker.
7. LD work string and haul off. Rig down service unit, clean location and back-fill reserve pit.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Robert McNaughton TITLE Operations Engineer DATE 8-28-00

Type or print name Robert McNaughton

Telephone No. 915 - 682 - 4429

(This space for State use)

APPROVED BY Mike Stillfield TITLE Field Rep. II DATE 9/19/2000  
Conditions of approval, if any:

\* Notify NMO.C.D. to witness Plugging Operations.