

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 87240  
District II  
811 South First, Artesia, NM 87210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

Form C-103  
Revised March 25, 1999

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. <b>30 - 015 - 30983</b>
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator <b>Nadel and Gussman Permian, L.L.C.</b>		6. State Oil & Gas Lease No. <b>VA - 1337</b>
3. Address of Operator <b>601 N Marienfeld, Suite 508, Midland, Texas 79701</b>		7. Lease Name or Unit Agreement Name: <b>Sammy State</b>
4. Well Location Unit Letter <b>E</b> : <b>1650'</b> feet from the <b>North</b> line and <b>660'</b> feet from the <b>West</b> line Section <b>15</b> Township <b>21-S</b> Range <b>25-E</b> NMPM <b>Eddy</b> County		8. Well No. <b>1</b>
1. Elevation (Show whether DR, RKB, RT, GR, etc.) <b>3414' GL, 3432' KB</b>		9. Pool name or Wildcat <b>Wildcat Morrow</b>

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☒  
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

SUBSEQUENT REPORT OF:


REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

OTHER: ☐  
Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Revised P&A procedure:

1. Notify Artesia NMOCD 24 hours prior to starting P&A. RU wireline. Shoot two squeeze perms at 455'.
2. TIH w/ work string open ended. Circulate casing and annulus with 10 PPG salt gel mud to surface.
3. Pump 35 sx "C" Neat plug on top of CIBP at 2125' and fill casing across intermediate shoe to 1900'.
4. Pump into SQZ perms and establish circulation. Pump 70 sx "C" to the surface. Close casing valve.
5. Pump 25 sx "C" (100' +) plug across surface casing shoe from 455' to 355'. WOC and tag cement.
6. Spot 10 sx "C" plug at surface. Cut-off wellhead and fill annulus with cement if necessary. Set standard 6' dry hole marker.
7. LD work string and haul off. Rig down service unit, clean location and back-fill reserve pit.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE  TITLE Operations Engineer DATE 5-9-01

Type or print name Robert McNaughton Telephone No. 915 - 682 - 4429  
(This space for State use)

APPROVED BY \_\_\_\_\_ TITLE Accepted for record - NMOCD DATE MAR 26 2002  
Conditions of approval, if any: