Plug & Abandon - Merland "28" No. 1

- 9-21-73 Rigged up DA&S pulling unit. Released Otis 4½" x 2" permalach packer & pulled 299 jts. 2-3/8", N-80, EUE, 8rd tubing, set CIBP w/electric line @ 9450', placed 35' of cement plug on top of CIBP w/dump bailer.
- 9-22 Ran 2-3/8" tbg. to 7500', mixed fresh water gel mud & displaced water out of well with mud, pulled 2-3/8" tubing, welded pull nipple on to 4½" casing, moved in and set casing jacks.
- 9-23 Cut off 4½" casing @ 7200', pulled & laid down 4½" casing joint count & tally will be reported later.
- 9-24 Shut down Sunday.
- 9-25 Ran 2" tubing to 7260'. Spotted cement plugs as follows:

35 sxs. (100') from 7260' to 7160' 35 sxs. (100') from 6400' to 6300' 35 sxs. (100') from 4900' to 4800' 70 sxs. (200') from 3400' to 3200'

70 sxs. (200') from 2650' to 2450'

Laid down all tubing and moved casing pulling equipment.

9-26 - Set 10 sx. cement surface plug in top of 8-5/8" below ground level, cut off casing head, welded steel cap on top 8-5/8" casing, fenced pits, and rigged down DA&S pulling unit. Well plugged & abandoned. Final report.

Casing left in hole

1134" - 320-ene.

834" - 2494-cist.

41/2" from 7200'-to 9813'