

5 - USGS

1 - File

MOCC COPY

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Copy to SF

Form approved.

Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM - 12841

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Cedar Canyon - 10 Cont

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Cedar Canyon-Morrow Gas

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 10-24S-29E

12. COUNTY OR PARISH 13. STATE

Eddy

New Mexico

1.

OIL ☐ GAS ☒ OTHER ☐

2. NAME OF OPERATOR

Getty Oil Company

3. ADDRESS OF OPERATOR

P.O. Box 730 Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

Unit letter F, 2180' FNL & 1980' FWL, Sec. 24S-29E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

2997" KB

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

Test lower morrow.

If unproductive, recomplete to Delaware

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- (1) Move in workover rig. Pull tubing and packer.
- (2) Latch onto on-off connector at 13,306'. Pull blanking plug.
- (3) Swab perfs 13,354'-13,366'. If zone flows, evaluate for stimulation.
- (4) If zone is unproductive, pull packer at 13,308'.
- (5) Latch onto on-off connector at 13,371'. Pull blanking plug.
- (6) Swab perfs 13,389'-13,411'. If zone flows, test and evaluate for stimulation.
- (7) If zone is unproductive, pull packer at 13,373'.
- (8) Set retainer at 12,800'. Squeeze morrow perfs with 190 sacks. Dump 10 sacks on top of retainer.
- (9) Run Schlumberger TDT Log from 5000' to 3000'.
- (10) Based on log, perforate the Delaware Sand.
- (11) Swab test, Acidize if necessary.
- (12) Install pumping equipment.

RECEIVED

AUG 17 1977

U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

David G. Abbott

TITLE Area Superintendent

DATE 8-12-77

(This space for Federal or State office use)

APPROVED BY

Joe G. Lora

TITLE ACTING DISTRICT ENGINEER

DATE AUG 19 1977

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side