

Submit 3 Copies To Appropriate District Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

Form C-103  
Revised March 25, 1999

CIS  
JP

WELL API NO. 30015-20759
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name: Esperanza
8. Well No. 3
9. Pool name or Wildcat Esperanza Delaware

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☒ Other

2. Name of Operator  
Concho Oil & Gas Corp.

3. Address of Operator  
110 W. Louisiana Ste 410; Midland, Tx 79701

4. Well Location

Unit Letter N : 660 feet from the South line and 1880 feet from the West line

Section 4 Township 22S Range 27E NMPM Eddy County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3122.8' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Concho Oil & Gas Corp. respectfully request approval to plug and abandon the Esperanza No. 3 well according to the following procedure:

1. Notify NMOCD-Artesia 24 hours prior to commencement of procedure.
2. RIH & set CIBP @ 2000' w/ 35' cmt on top.
3. Shoot squeeze holes @  $\pm$  1680' & circ cmt to surface.
4. Set 100' plug @ 1924-1824' (Int. csg). WOC & tag.
5. Set 100' plug @ 383-283' (surf csg).
6. Set 10 sx surface plug.
7. Cut off wellhead & install dry hole marker.

Notify OCD 24 hrs. prior to any work done

Salt gel mud consisting of 10#  
Brine W/25# of gel per bbl  
must be placed between each plug



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terry Spethem TITLE Production Analyst DATE 9-26-01  
Type or print name Telephone No. 915-683-7443

(This space for State use)  
APPROVED BY Wild Dog TITLE Wild Dog DATE 10-5-01  
Conditions of approval, if any: