## NM OIL CONS COMMISSION Drawer DD Artesia, NM 88210

Form 3160-5 June 1990)

Approved by Conditions of approval, if any:

## UNITED STATES

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT 5. Lease Designation and Serial No. NM-0501759 SUNDRY NOTICES AND REPORTS ON WELLS 6. If Indian, Allottee or Tribe Name Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals 7. If Unit or CA, Agreement Designation SUBMIT IN TRIPLICATE 1. Type of Well Oil Well X Gas Well 8. Well Name and No. Avalon Hills AOQ Fed Com #1 2. Name of Operator 9. API Well No. (505) 748-1471)YATES PETROLEUM CORPORATION 30-015-21073 3. Address and Telephone No. 105 South 4th St., Artesia, NM 88210 10. Field and Pool, or Exploratory Area 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Undes. Strawn 660' FSL & 1980' FWL of Section 7-T21S-R27E (Unit N, SESW) 11. County or Parish, State Eddy Co., NM CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF ACTION TYPE OF SUBMISSION XX Abandonment X Notice of Intent Change of Plans **New Construction** Recompletion Non-Routine Fracturing Subsequent Report Plugging Back Water Shut-Off Casing Repair Conversion to Injection Altering Casing Final Abandonment Notice Dispose Water Other (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\* Jim Brown, engineer with Yates Petroleum Corporation, received verbal permission from Shannon Shaw w/BLM - Carlsbad, on October 25, 1994, to plug and abandon well as follows: Set a 100 sack cement plug at approximately 1600' where bad casing was encountered. Will tag plug and pump more cement if necessary. Either: A. If cement in Step #1 holds, set 100' plug at 670'. Tag plug only if fluid level in casing drops. Set 50' surface plug. If cement in Step #1 does not hold, set a CIBP at 670' and cap with 100' cement. Set 50' surface plug. 14. I hereby certify that the foregoing is/true and correct Production Clerk Title (ORIG. SGD.) JOE G. LARA

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.