

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION
RECEIVED

MAR 8 1976

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK EXISTING RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5. State Oil & Gas Lease No. 6. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
1. Name of Operator Cities Service Oil Company ✓		7. Unit Agreement Name Walterschied Com.
2. Address of Operator Box 1919 - Midland, Texas 79701		8. Term of Lease Date 1
3. Location of Well UNIT LETTER <u>G</u> <u>2240</u> FEET FROM THE <u>North</u> LINE AND <u>1830</u> FEET FROM THE <u>East</u> LINE, SECTION <u>35</u> TOWNSHIP <u>22S</u> RANGE <u>27E</u> NMPM.		9. Well No. 1
15. Elevation (Show whether DE, RT, GR, etc.) 3083' GR		12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated dates of any proposed work) SEE RULE 1103.

T.D. 12460' Shale PBTD 12400'. We propose to plug and abandon this well in the following manner:

1. MIRU casing puller, load tubing with water, unseat packer and pull tubing and packer set @ 11910'. *at 11875' + 35X Cement witnessed by NE*
2. Set a CIBP @ approx. 11900' and dump 4 sacks of cement on top of CIBP @ approx. 11900' - 11865' to plug off the Morrow Perfs @ 11958 - 11968'.
3. Cut off 4-1/2" casing @ approx. 10000' and pull casing out of the hole.
4. Run 2-3/8" OD open ended tubing and circulate the hole with mud laden fluid.
5. Displace a 60 sack cement plug @ approx. 10100 - 9925' (1/2 in and 1/2 out of the 4-1/2" casing stub @ approx. 10000').
6. Displace a 60 sack cement plug across top of Wolfcamp (9058') @ approx. 9135 - 8985'.
7. Displace a 60 sack cement plug across top of 2nd Bone Springs Sand (7375') @ approx. 7450 - 7300'.
8. Displace a 60 sack cement plug across top of Bone Springs (5670') @ approx. 5750 - 5600'.
9. Displace a 40 sack cement plug @ approx. 4625 - 4525' (1/2 in and 1/2 out of 9-5/8" casing shoe @ 4576'.
10. Displace a 10 sack cement surface plug @ approx. 58 - 0' and install a 4" dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. J. Pender TITLE Region Operation Manager

March 4, 1976

APPROVED BY W. A. Gressett TITLE SUPERVISOR, DISTRICT II

DATE MAR 12 1976

CONDITIONS OF APPROVAL, IF ANY: