

OIL CONSERVATION DIVISION
P.O. BOX 2088
SANTA FE, NEW MEXICO 87501

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
L-3358

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT ZONE. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Mesa Operating Limited Partnership ✓ 3. Address of Operator P. O. Box 2009 Amarillo, Tx 79189 4. Location of Well UNIT LETTER <u>D</u> <u>685</u> FEET FROM THE <u>North</u> LINE AND <u>1295</u> FEET FROM THE <u>West</u> LINE, SECTION <u>18</u> TOWNSHIP <u>23S</u> RANGE <u>30E</u> NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 3012' GR	7. Unit Agreement Name 8. Farm or Lease Name NASH UNIT 9. Well No. 7 10. Field and Pool, or Wildcat Nash Draw Morrow 12. County EDDY
---	--

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to Plug & Abandon as follows:

Set cement retainer @ 6850' inside 5½" casing above 4½" drill pipe @ 6912'. Squeeze Morrow perfs (13,624'-13,859') and fill volume below retainer including 50' plug above retainer with 500 sx Class "H". Displace hole with 9.0 ppg mud laden fluid. Set 25 sx Class "H" balanced plug 4250'-4475' across Cherry Canyon top @ 4354'. Set 25 sx Class "H" balanced plug 3150'-3375' across 13⅜" casing shoe @ 3265'. Set 25 sx Class "H" balanced plug 300-525' across the 20" casing shoe @ 410'. Set 10 sx Class "H" cement plug @ 100' to surface. Cement 9⅝ x 5½ casing annulus to surface through 1" pipe with Class "H" Cement. Install dry hole marker.

Notify N.M.O.C.C. in sufficient time to witness

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Carelyn Cummings TITLE Regulatory Analyst DATE 6-23-88

APPROVED BY Danell Moore TITLE Geologist DATE 6/29/88

CONDITIONS OF APPROVAL, IF ANY:

xc: NMOCD-A (0+2), Prod Rcds, Reg, Land, Expl., C. Records, Partners