

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

APR 22 1993

WELL API NO. 30-015-23317
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. L-4502
7. Lease Name or Unit Agreement Name Little Bear State Unit
8. Well No. 2
9. Pool name or Wildcat Wildcat

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER
2. Name of Operator Siete Oil and Gas Corporation
3. Address of Operator P.O. Box 2523, Roswell, NM 88202-2523
4. Well Location Unit Letter <u>E</u> : <u>2030</u> Feet From The <u>North</u> Line and <u>1085</u> Feet From The <u>West</u> Line Section <u>18</u> Township <u>24S</u> Range <u>25E</u> NMPM <u>Eddy</u> County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4360' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☒  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Siete Oil and Gas Corporation respectfully requests permission to P&A the above captioned well as follows:

1. Set CIBP @ 5125', spot 35' cement on CIBP using 4 sxs "C".
2. Cut off 5½" csg @ 2880', lay dn csg, set plug @ 2950'-2850' w/25 sxs "C", 3% S-1, tag plug.
3. Set plug @ 2140'-2040' w/25 sxs "C".
4. Set plug @ 1310'-1210' w/25 sxs "C".
5. Set plug @ 350'-250' w/ 25 sxs "C", if FL is standing @ surface after setting this plug proceed to step 6, if FL is not standing @ surface tag plug.
6. Set plug @ 15'-surface w/5 sxs "C", install dry hole marker, clean & level location.

This method was approved by Ray Smith on 4/19/93.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Cathy Batley-Seely TITLE Drilling Technician DATE 4/20/93  
TYPE OR PRINT NAME \_\_\_\_\_ TELEPHONE NO. \_\_\_\_\_

(This space for State Use)

ORIGINAL SIGNED BY  
MIKE WILLIAMS  
SUPERVISOR, DISTRICT II

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

MAY 10 1993

Plugging