

Proposal for recompletion to Bone Springs formation
Attachment to form C-101
September 25, 1989

The proposed procedure for recompleting in the Bone Springs is as follows:

1. Set CIBP @ 12,220' (Above morrow zone) and dump 35' cmt on top.
2. Perf Middle Bone Springs @ 7842'-65' & 7881'-94' w/1 JSPF.
3. Acidize w/2000 gals. 15% HCL.
4. If productive of oil or gas, acid frac w/9000 gals. gelled water & 9000 gals. gelled acid in 2 stages.
5. If dry, set CIBP @ 7820' and dump 35' cmt on top.
6. Perf Upper Bone Springs @ 6599'-7117' o.a. w/60 JS.
7. Acidize w/6000 gals. 15% HCL.
8. Frac w/60,000 gals GW and 115,000# sand.
9. Set RBP @ 6575'.
10. Perf Upper Bone Springs @ 6250'-6472' o.a. w/29 JS.
11. Acidize w/3000 gals. 15% HCL.
12. Frac w/60,000 gals. GW & 115,000# sand.
13. Retrieve BP and equip to pump.

1A - Spot 25 sk cmt @ 11,340
1B - Spot 25 sk cmt @ 9450